

PRINTER ALIGNMENT TEST PAGE

Grid must be perfectly square. Bent or doubled lines = misaligned printhead.

